# Enhanced Push-to-Talk (EPTT)
Quick Start Guide

Phone at a Glance

KYOCERA

< Top >

Headset jack

< Front >

LED indicator

Proximity/
Light sensor

Tertiary
microphone

Earpiece

Front camera

Touchscreen

Primary
microphone

Quaternary
microphone

Speakers

< Bottom >

USB/Charger port

< Sides >

Power key

Volume key

PTT/Programmable
key

SIM/microSD
card slot

Camera key

< Back >

Back camera
Wide view
camera

Wireless
charging area

Secondary
microphone

Flash

2

Notification Icons

Icon	Status
☑	PTT available
☒	PTT offline
⊘	PTT do not disturb
☎	Missed call
✉	New mail
💬	New message
31	Event
♪	Music application is running in the background
⏰	Alarm
↓	Downloading

Initial Activation of EPTT

KYOCERA

Install the EPTT Application

1. From the home screen, tap ⋮⋮⋮ > **AT&T EPTT**.

Note: Upon first access, the application download screen on Google Play Store is displayed. Follow the on-screen prompts to complete the update.

Initial Activation of EPTT

Activate the EPTT

1. Review the End User License Agreement, then tap the Checkmark icon.

2. Review the Confirm activation prompt, then tap Yes.

Initial Activation of EPTT

3. Tap **View Tutorial** to view a tutorial on AT&T Enhanced Push-to-Talk.
    - or –
    Tap **Skip Tutorial** to continue to the application without viewing the tutorial.

    Note: The tutorial can be viewed later in the AT&T Enhanced Push-to-Talk Settings. From the AT&T EPTT application, tap ☰ > ***Tutorial****.*

Assign a EPTT to PTT key

## Assign a EPTT to PTT key

1. From the home screen, tap ⊕ > **Settings** > **Programmable keys** > **PTT key**.

2. Tap **AT&T EPTT**.

Assign a EPTT to PTT key

1. From the home screen, press the **PTT key** and tap **ASSIN**.
2. Tap **AT&T EPTT**.

   *Note: If you do this before installing and activating the application, you will see **Install AT&T EPTT** instead of **AT&T EPTT**. Tap **Install AT&T EPTT** to install the EPTT application.*

PTT key

Assign a EPTT to Camera key

KYOCERA

Assign a EPTT to Camera key

1. From the home screen, tap ⊞ > **Settings** > **Programmable keys** > **Camera key**.

2. Tap the **AT&T EPTT**.

EPTT Menu Icons

KYOCERA

History: Displays all your conversation history of calls, contacts, groups, alerts, messages (text, image, video, and voice).

Favorites: Displays your favorite EPTT contacts and talk groups.

Contacts: Displays EPTT contacts and allows to create/edit/delete a contact or initiate an EPTT call

Group: Displays EPTT talk groups and allows to created/edit/delete a group or initiate a group call.

Location: Displays your location and allows you to send your location to others.

Contacts

Add a Contact

1. Tap ⊕ > **AT&T EPTT**.
2. Tap 👤 > ⊕ .
3. Tap **New Contact**.
4. Enter the contact's name and phone number.
5. Tap ✓ .

Contacts

Add a Contact

1. Tap ⊞ > **AT&T EPTT**.
2. Tap 👤 > ⊕ .
3. Tap **Import Contact**
4. Select the contact you want add.
5. Tap ✓ .

Contacts

Delete a Contact

1. Tap ⊕ > **AT&T EPTT**.
2. Tap 👤 .
3. Tap and hold the contact you want to delete.
4. Tap **Details**.
5. Tap 🗑 > **Yes**.

Contacts

Add a Group Contact

1. Tap ⊙ > AT&T EPTT
2. Tap 👥 > ⊕ .
3. Enter the group's name, tap ⊕ to add the members.
4. Select the check box next to the contact(s) you want to add.
5. Tap ✓ > ✓ .

Contacts

Add a Contact to Favorite

1. Tap ⊕ > **AT&T EPTT**.
2. Tap ☆ > ⊕ .
3. Select the check box next to the contact(s) you want to add.
4. Tap ✅ .

Settings

Alert Tone

1. Tap ⊕ > **AT&T EPTT**.

2. Tap ☰ > **Settings** > **Alert Tone**.

3. Select the desired tone (Alert1, Alert2, Alert3 or Alert4) and tap **OK**.

Make a Call

1. Tap ⊛ > AT&T EPTT
2. Tap 👤 and tap the desired contact to call.
3. Press and hold the **PTT key** or blue microphone icon and begin speaking to make a call. The Microphone icon will be highlighted with a blue background.
4. After speaking, release the **PTT key** or microphone icon.

PTT key

End a Call

1. Tap > AT&T EPTT