### Sprint ID

Sprint ID makes it effortless to personalize your mobile device with a cohesive suite of ringtones, wallpapers, apps and widgets designed to fuel your aspirations. Just choose the theme or themes that interest you – from fitness to productivity – and with one click, all the parts and pieces of your total mobile experience download to your device automatically. And since the catalog of experiences will continue to evolve over time, the latest apps and options designed to fit your lifestyle are always in the palm of your hand.

### Fashion & Beauty ID Pack

The Fashion & Beauty ID Pack delivers a customized experience for keeping you connected and up to date on the latest fashion trends and celebrity gossip. Features all the best resources for beauty, style, entertainment and more.





### Socially Connected ID Pack

The Socially Connected ID Pack delivers a customized experience for keeping you connected with friends on the go. Features Facebook, Twitter apps and more, creating the ultimate starting point for your own, multi-tasking, socially connected mobile life.





### MTV Music ID Pack

The MTV Music ID pack is a complete music experience, bringing together the best music and pop culture apps, widgets and content on your Milano. MTV gives you access to the biggest stars and newest artists around the clock. Plus, we've selected the best music apps to stream, download, identify, search and discover all your favorite music.





### Operating System

Android 2.3 (Gingerbread)

#### Chipset

MSM7627T 800 MHz

### Memory

512MB/512MB

#### Radios

 $4.1 \times 2.4 \times 0.7$  in  $(105.0 \times 61.0 \times 17.1 \text{ mm})$ 

### Weight

5.6 ounces (158 grams)

### Battery Type

### Media Formats

Video: MPEG, H.263, H.264

### Bluetooth® (version 2.1)

- AV Remote Control Profile (AVRCP)

- Hands-Free 1.5 Profile (HFP1.5)
- Headset Profile (HSP)
- Object Exchange (OBEX)
- Phone Book Access Profile (PBAP)
- Message Access Profile (MAP)





### Talk Time

Up to 7.65 hours

2GB included; up to 32GB (optional)

CDMA EV-DO rev. 0 dual-band digital (800, 1900 MHz)

### Size

1490 mAh Lithium ion (Lilon)


Audio: MPEG, WAV, EVRC, AAC, 3GPP/3GPP2

Image: JPEG, BMP, GIF, PNG

### Profiles:


- Advanced Audio Distribution Profile (A2DP)
- General A/V Distribution Profile (GAVDP)
- Generic Object Exchange Profile (GOEP)

- Object Push Profile (OPP)









Times will vary based on user settings, feature use and network configuration

### Display Specifications

3.0" capacitive touchscreen, QVGA (320 x 240 pixels) TFT LCD, 262K-color













http://iteachu.kyocera-wireless.com/sprint

Product Information www.kyocera-wireless.com

Consumer Support 1-800-349-4478 phone-help@kyocera-wireless.com

Kyocera Communications, Inc. 9520 Towne Centre Drive, San Diego, CA 92121 USA 1-800-349-4188, Outside USA +1-858-882-1400

Follow us on Facebook www.facebook.com/kyoceramobilephones









©2011 Kyocera Communications, Inc. (KCI), San Diego, CA, USA. All rights reserved. KYOCERA is a registered trademark of Kyocera Corporation. Sprint and other trademarks are the trademarks of Sprint. The Bluetooth word mark and logos are owned by the Bluetooth SIG, Inc. and any use of such marks is under license. Google, Android and Android Market are trademarks of Google, Inc. Other trademarks and trade names are those of their respective owners. Because its products are subject to continuous improvements, KCI reserves the right to modify design, features and specifications without notice.

Certain features may require optional services and may involve additional charges. Screen images are simulated. Not all products may be available in your area.

Printed in USA 9/11 TMM002224-1







http://iteachu.kyocera-wireless.com/sprint

# Plays well with others.

With pre-loaded Google™ apps and access to Android Market™, the world is your playground with Milano.

### Highlights

Powered by Android™ 2.3

Touchscreen with slide-out QWERTY keyboard

3.2 MP camera with auto-focus and video camcorder

Eco Mode — a battery power management application

Sprint ID customizable UI

### Apps & Messaging

Google™ Mobile services including Google Search™, Google Maps™, Google Talk™, Google Calendar™, Google Voice™, Google Latitude™, Gmail™, and YouTube™

Integrate your address book with Gmail, Exchange and Facebook™

Full HTML web browser

Corporate (Exchange ActiveSync) and personal (POP3 & IMAP) email

Media player and high-quality video streaming

Sprint Zone<sup>™</sup> — one-stop wireless account access, phone tips, news and more

Access to Sprint Navigation, Sprint TV & Movies and NASCAR

Swype — a faster and easier way to type

#### Camera

3.2 MP camera with auto-focus and video camcorder

microSD memory card slot for storing and transferring photos

### Connectivity

### Wi-Fi (802.11 b/g/n)

Wi-Fi hotspot capability (supports up to 5 devices)\*

Stereo Bluetooth (2.1 + EDR) wireless technology

3.5mm stereo headset jack

### Memory & Sensors

512MB/512MB internal memory

2GB microSD™ memory card included (supports up to 32GB)

Accelerometer, Proximity Sensor, Ambient Light Sensor, Digital Compass

### Additional Features

Bilingual user interface, English and Spanish

Hearing aid capability (HAC): Rating M4/T4. TTY capable

\*Additional fees apply

# Highlights



## Swype®

Swype provides a faster and easier way to input text on any screen. With one continuous finger motion across the screen keyboard, the patented technology enables users to input words faster and easier than other data input methods. In addition Swype supports predictive tap.







Example: cool For double letters, circle the letter.

Example: You

letter, slide up

To capitalize the

over the keyboard.

Place your finger on

etter of the word and

### Eco Mode

The Eco Mode allows you to save battery life while using your device.

- 1. Press Home 🎓 and Touch 🧰 > Eco Mode.
- 2. Drag the on-screen slider to select when you use the Eco Mode.
- > Always: Sets your device to always use the Eco Mode.
- > 10 90% Selects the remaining battery power when the Eco Mode activates. For example, 40% means the Eco Mode activates when the remaining battery power reaches 40%.
- > Never: Disables Eco Mode.



- 3. Touch Eco settings to select the Eco Level.
- 4. Touch the leaf of the following items to select. > Screen timeout to set the screen timeout to
- 15 seconds. > Display brightness to decrease the display
- brightness. > Wallpaper to select the Eco wallpaper.
- > Auto-sync to disable synchronizing the applications.

- > Haptic feedback to turn off Haptic feedback feature.
- > Auto-sync to disable synchronizing the applications.



5. Touch Close.

When Eco Mode is on, the Eco Mode icon appears on the status bar.



Configured settings in the Eco Mode are automatically reflected in the respective Settings menu and vice versa.



